

# **Development of Micromachines Using Deep X-Ray Lithography**

**Ming X. Tan**


# Outline

- **Background of LIGA process.**
- **Examples of LIGA fabricated micromachine parts.**
- **Material studies in LIGA:**
  - **Research on the development of PMMA resists**


# LIGA

(Lithographie, Galvanoformung, Abformung)  
(Deep x-ray lithography, electroplating, molding)

## Synchrotron






# Development and Electroplating




# Molding


Injection Molding  
→  
or Metal Plating



Plastic




Ceramic




Metal Alloy

# LIGA vs. Si micro-lithography

Surface  
Dimension



Vertical  
Depth



Vertical  
Slope



# LIGA Advantages

- Provides unique dimensions for microdevices:
- Fabricates devices of various materials:

Metal, alloy metal

Polymers, bio-compatible polymers

Resins with special optical properties

High temperature ceramics

- Molding process provides possibility of simple mass production.

## Limits

- Assembly

# LIGA Activities in California

**SSRL**  
(Stanford)

**Private Industry**

**ALS**  
(LBNL)


**Sandia National Labs, CA**

**Jet Propulsion Lab**

**Lawrence Berkeley  
National Lab**


**NSRL**  
(BNL)

**University of California, Berkeley**  
**(Mechanical Engineering Dep.)**





# LIGA Applications - Chemical Sensor Miniaturization



**Mass Spectrometer (JPL/SNL),  
for 1-300 AMU detection.**




**Micro Electrochromatography  
(SNL), 360  $\mu\text{m}$  capillary tube in  
a  $360 \pm 1.5 \mu\text{m}$  hole, 2.3 mm deep.**

# Micro Electrochromatography

Micro-capillary tubes

O.D. =  $360\text{ }\mu\text{m}$


I.D. =  $78\text{ }\mu\text{m}$




Micro-channel

W =  $78\text{ }\mu\text{m}$


H =  $80\text{ }\mu\text{m}$




gradient



injection





gradient+injection



reaction + injection

# LIGA Applications - Actuators





**Size 5 Stepper - Stator (LBNL/SNL)**

**Step Size 1.8 Degree, Ni/Fe Alloy**


**Requires very vertical side wall and high precision**

## LIGA Applications - High Precision Micro Devices



Solar Grid (JPL/SNL), 16  $\mu\text{m}$  wide, 1mm tall gold grids.


# Lockheed Martin/SNL Heat Pipe




# Material Issues in LIGA Fabrication

- LIGA mask fabrication;
- **PMMA development as functions of exposure;**
- PMMA attachment to metals;
- Plating in high aspect ratio deep channels, plating of different metals and alloys;
- Molding;
- Material characterization, tolerance, mechanical property measurements.

# What Controls Development Rate ?



**Development Rate**  
**PMMA Chain Length**  
**Exposure Dose**




## Some Other Factors:

PMMA properties  
Dev. Temp.  
Exp. Condition  
Pre-treatment



# Approach to Produce Development Curves


Exposure Mask



Development




1/4"




Repeat same experiment w/ many samples of different exposure.

Development curve from one exposure.






## Development Curve From One Exposure




$f(t)$  - Thickness of PMMA dissolved with time

# Experimental Set-up




## PMMA Dissolved Thickness vs. Time



$$\text{Dissolved} = f(t) = -a + b \log(t)$$
$$\frac{df}{dt} = \frac{b \log(e)}{t}$$


$$\text{Development Rate}(f) = \frac{b \log(e)}{[10^{(f+a)/b}]}$$

# Development Curves from 3 Exposures




**Development curve can be obtained with single exposure.**

# Development Rate vs. Polymer Property




**GFPMAA-cq has similar development curve as Plex-G.**

# LIGA Material Characterization



**SNL Compression/Tensile Testing Parts**  
**600  $\mu\text{m}$  wide (middle), 1mm thick**

# SNL/UCB/LBNL Tolerance Test



Testing:  
Roundness  
Angularity  
Concentricity  
Dimensional Accuracy  
Aspect Ratio

## Summary

- We have made many advances in LIGA material and process development, such as PMMA development, plating, etc.
- Through collaborations with UCB, LBNL, JPL, we have successfully fabricated micromachine parts for a variety of applications.



# Acknowledgment

**Schondelle Wilson**

**Bill Bonivert (SNL)**

**Jill Hruby (SNL)**

**Julie Lee (LBNL)**

**Dean Wiberg (JPL)**

**Michelle Bankert (SNL)**

**Dale Boehme (SNL)**

**Keith Jackson (LBNL)**

**Reid Brennen**